

| | | | | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Install 9v battery in EDS | | | | | | | | | | | | | | | | | | | | |
| Attach regulator valve to cylinder—HAND TIGHTEN ONLY. Do not use wrench. | | | | | | | | | | | | | | | | | | | | |
| Attach RED or CLEAR tube to Regulator. Check connection | | | | | | | | | | | | | | | | | | | | |
| Attach RED tube to RED connector on EDS. Check connection | | | | | | | | | | | | | | | | | | | | |
| Attach cannula or mask to BLUE connector on EDS. Check connection | | | | | | | | | | | | | | | | | | | | |
| Turn cylinder valve on | | | | | | | | | | | | | | | | | | | | |
| Turn EDS on— Set to "N" mode. Verify beep and O2 pulse | | | | | | | | | | | | | | | | | | | | |
| Don cannula, take a breath. Green light should illuminate and a pulse of O2 delivered | | | | | | | | | | | | | | | | | | | | |
| For cannula set to D5 (activates at 5m ft.), or D10 (activates at 10m ft.) | | | | | | | | | | | | | | | | | | | | |
| Use face mask above 18,000 ft. Set to F5, F10, F15, or F20. Consult instruction manual | | | | | | | | | | | | | | | | | | | | |
| R/M Setting— Equivalent to 100% oxygen flow for emergency oxygen delivery | | | | | | | | | | | | | | | | | | | | |
| DATE | | | | | | | | | | | | | | | | | | | | |
| NAME | | | | | | | | | | | | | | | | | | | | |

PW-6U Oxygen System Preflight

| | | | | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Install 9v battery in EDS | | | | | | | | | | | | | | | | | | | | |
| Attach regulator valve to cylinder—HAND TIGHTEN ONLY. Do not use wrench. | | | | | | | | | | | | | | | | | | | | |
| Attach RED or CLEAR tube to Regulator. Check connection | | | | | | | | | | | | | | | | | | | | |
| Attach RED tube to RED connector on EDS. Check connection | | | | | | | | | | | | | | | | | | | | |
| Attach cannula or mask to BLUE connector on EDS. Check connection | | | | | | | | | | | | | | | | | | | | |
| Turn cylinder valve on | | | | | | | | | | | | | | | | | | | | |
| Turn EDS on— Set to "N" mode. Verify beep and O2 pulse | | | | | | | | | | | | | | | | | | | | |
| Don cannula, take a breath. Green light should illuminate and a pulse of O2 delivered | | | | | | | | | | | | | | | | | | | | |
| For cannula set to D5 (activates at 5m ft.), or D10 (activates at 10m ft.) | | | | | | | | | | | | | | | | | | | | |
| Use face mask above 18,000 ft. Set to F5, F10, F15, or F20. Consult instruction manual | | | | | | | | | | | | | | | | | | | | |
| R/M Setting— Equivalent to 100% oxygen flow for emergency oxygen delivery | | | | | | | | | | | | | | | | | | | | |
| DATE | | | | | | | | | | | | | | | | | | | | |
| NAME | | | | | | | | | | | | | | | | | | | | |

PW-6U Oxygen System Preflight