

Install 9v battery in EDS																				
Attach regulator valve to cylinder—HAND TIGHTEN ONLY. Do not use wrench.																				
Attach RED or CLEAR tube to Regulator. Check connection																				
Attach RED tube to RED connector on EDS. Check connection																				
Attach cannula or mask to BLUE connector on EDS. Check connection																				
Turn cylinder valve on																				
Turn EDS on— Set to “N” mode. Verify beep and O2 pulse																				
Don cannula, take a breath. Green light should illuminate and a pulse of O2 delivered																				
For cannula set to D5 (activates at 5m ft.), or D10 (activates at 10m ft.)																				
Use face mask above 18,000 ft. Set to F5, F10, F15, or F20. Consult instruction manual																				
R/M Setting— Equivalent to 100% oxygen flow for emergency oxygen delivery																				
DATE																				
NAME																				

PW-6U Oxygen System Preflight

Install 9v battery in EDS																				
Attach regulator valve to cylinder—HAND TIGHTEN ONLY. Do not use wrench.																				
Attach RED or CLEAR tube to Regulator. Check connection																				
Attach RED tube to RED connector on EDS. Check connection																				
Attach cannula or mask to BLUE connector on EDS. Check connection																				
Turn cylinder valve on																				
Turn EDS on— Set to “N” mode. Verify beep and O2 pulse																				
Don cannula, take a breath. Green light should illuminate and a pulse of O2 delivered																				
For cannula set to D5 (activates at 5m ft.), or D10 (activates at 10m ft.)																				
Use face mask above 18,000 ft. Set to F5, F10, F15, or F20. Consult instruction manual																				
R/M Setting— Equivalent to 100% oxygen flow for emergency oxygen delivery																				
DATE																				
NAME																				

PW-6U Oxygen System Preflight